

Broil King®



Broil King

CROWN 420

8652-52

8652-53



Broil King

CROWN S 420

8653-52

8653-53



Broil King

CROWN 440

8652-62

8652-63



Broil King

CROWN S 440

8653-62

8653-63



Broil King

CROWN 490

8652-82

8652-83



Broil King










CROWN S 490

8653-82


8653-83




HARDWARE INCLUDED

S21124		(4)	Y-29304		(2)
Y-12865		(22)	Y-11793		(4)
Y-11551		(2)	Y-12124		(2)
56039-214A		(1)	Y-11229		(1)
S21235		(2)	S21233		(2)
32001-151		(4)			
20005-000					(1)






TOOLS REQUIRED



1





2






3

(8)







4



5


(2)




6


(2)





(1)



7

(2) 









9

(4)


(1)

(1)







Broil King
BARBECUE

10





11







13





(4)




14

(6)







16






17






18

(2)






19




(1)




20


(1)









23




(2)




(2)





25



PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	8652-52	8652-53	8652-62	8652-63	8652-82	8652-83	8653-52	8653-53	8653-62	8653-63	8653-82	8653-83
1	50909-E441	CASTING BOTTOM	1	1	1	1	1	1	1	1	1	1	1	1
2	56005-801	LID ASSEMBLY	1	1	1	1	1	1	•	•	•	•	•	•
	56005-804	LID ASSEMBLY	•	•	•	•	•	•	1	1	1	1	1	1
3	52019-911	FIRE BOX END CAP - LH	1	1	1	1	1	1	1	1	1	1	1	1
4	52019-931	FIRE BOX END CAP - RH	1	1	1	1	1	1	1	1	1	1	1	1
5	52049-042	HEAT SHIELD	3	3	3	3	3	3	3	3	3	3	3	3
6	52049-142	HEAT SHIELD	1	1	1	1	1	1	1	1	1	1	1	1
7	Y-11544S	SCREW - BURNER	4	4	4	4	4	4	4	4	4	4	4	4
8	S21242	BURNER CLIP	4	4	4	4	4	4	4	4	4	4	4	4
12	52315-151	HOOD PANEL	1	1	1	1	1	1	1	1	1	1	1	1
13	52035-914	FIRE BOX FRONT TRIM	1	1	1	1	1	1	1	1	1	1	1	1
18	52002-981	COOKING GRID	4	4	4	4	4	4	4	4	4	4	4	4
20	52005-991	GRID - WARMING RACK	1	1	1	1	1	1	1	1	1	1	1	1
21	59805-012	CONTROL ASSEMBLY	1	•	•	•	•	•	1	•	•	•	•	•
	59805-013	CONTROL ASSEMBLY	•	1	•	•	•	•	•	1	•	•	•	•
	59805-032	CONTROL ASSEMBLY	•	•	1	•	•	•	•	•	1	•	•	•
	59805-033	CONTROL ASSEMBLY	•	•	•	1	•	•	•	•	•	1	•	•
	59805-072	CONTROL ASSEMBLY	•	•	•	•	1	•	•	•	•	•	1	•
	59805-073	CONTROL ASSEMBLY	•	•	•	•	•	1	•	•	•	•	•	1
22	52015-903	COLLECTOR BOX	1	1	1	1	1	1	1	1	1	1	1	1
24	10111-16A	CONNECTOR HOSE	1	1	1	1	1	1	1	1	1	1	1	1
25	52924-144D	BURNER	1	•	1	•	1	•	1	•	1	•	1	•
	52924-144E	BURNER	•	1	•	1	•	1	•	1	•	1	•	1
26	52002-298A	CONTROL KNOB	4	4	4	4	4	4	4	4	4	4	4	4
27	52001-298A	CONTROL KNOB	•	•	1	1	2	2	•	•	1	1	2	2
28	52025-124CRO	CONTROL COVER	1	1	•	•	•	•	1	1	•	•	•	•
	52025-244CRO	CONTROL COVER	•	•	1	1	•	•	•	•	1	1	•	•
	52025-304CRO	CONTROL COVER	•	•	•	•	1	1	•	•	•	•	1	1
31	52009-918	EDGE CAP - LH	1	1	1	1	1	1	1	1	1	1	1	1
32	52009-938	EDGE CAP - RH	1	1	1	1	1	1	1	1	1	1	1	1
34	S13473-073	HOSE-SIDE BURNER	•	•	1	•	1	•	•	•	1	•	1	•
	S13473-079	HOSE-SIDE BURNER	•	•	•	1	•	1	•	•	•	1	•	1
34A	Y-11230	COTTER PIN	•	•	1	1	1	1	•	•	1	1	1	1
35	52039-101	SIDE BRACE	2	2	2	2	2	2	2	2	2	2	2	2
36	52809-957	TUBE-REAR BURNER ASSY	•	•	•	•	1	1	•	•	•	•	1	1
37	53139-908	SHELF BRACKET SUPPORT	4	4	4	4	4	4	4	4	4	4	4	4
38	Y-12620	SHELF LOCK CLIP	4	4	4	4	4	4	4	4	4	4	4	4
39	52045-111	BRACE - FRONT / REAR	2	2	2	2	2	2	2	2	2	2	2	2
41	10342-E13	ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1
42	10342-E22	ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1
44	10342-42	ELECTRONIC IGNITOR	1	1	•	•	•	•	1	1	•	•	•	•
	10342-43	ELECTRONIC IGNITOR	•	•	1	1	•	•	•	•	1	1	•	•
	10342-44	ELECTRONIC IGNITOR	•	•	•	•	1	1	•	•	•	•	1	1

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	8652-52	8652-53	8652-62	8652-63	8652-82	8652-83	8653-52	8653-53	8653-62	8653-63	8653-82	8653-83
44A	25070-925	WIRE - IGNITOR	1	1	1	1	1	1	1	1	1	1	1	1
44B	25070-931	BUTTON - IGNITOR	1	1	1	1	1	1	1	1	1	1	1	1
48	52004-007	DRIP PAN	1	1	1	1	1	1	1	1	1	1	1	1
49	51009-007	GREASE PAN	1	1	1	1	1	1	1	1	1	1	1	1
50	52059-101	GREASE RAIL	1	1	1	1	1	1	1	1	1	1	1	1
51	52009-104	FLAV-R-WAVE ®	4	4	4	4	4	4	4	4	4	4	4	4
52	52349-004	GREASE SHIELD	1	1	1	1	1	1	1	1	1	1	1	1
53	52249-004	GREASE SHIELD	2	2	2	2	2	2	2	2	2	2	2	2
54	52049-004	GREASE SHIELD	1	1	1	1	1	1	1	1	1	1	1	1
56	24005-12A	HANDLE	1	1	1	1	1	1	1	1	1	1	1	1
58	54009-936	BEZEL	2	2	2	2	2	2	2	2	2	2	2	2
59	10081-BK630	NAMEPLATE	1	1	1	1	1	1	1	1	1	1	1	1
60	10571-6	HEAT INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1
65	20005-000	MATCH LIGHT - STICK	1	1	1	1	1	1	1	1	1	1	1	1
68	51275-111A	DOOR	1	1	1	1	1	1	•	•	•	•	•	•
	51275-114A	DOOR	•	•	•	•	•	•	1	1	1	1	1	1
69	51275-131A	DOOR	1	1	1	1	1	1	•	•	•	•	•	•
	51275-134A	DOOR	•	•	•	•	•	•	1	1	1	1	1	1
70	21071-13	HANDLE	2	2	2	2	2	2	2	2	2	2	2	2
71	21070-13	BEZEL	4	4	4	4	4	4	4	4	4	4	4	4
78	56039-214	MAGNET BRACKET	1	1	1	1	1	1	1	1	1	1	1	1
80	51189-101	SIDE PANEL	2	2	2	2	2	2	2	2	2	2	2	2
81	Y-11992	SCREW 1/4-20 x 2 1/4	4	4	4	4	4	4	4	4	4	4	4	4
87	Y-11793	NUT 1/4-20	12	12	12	12	12	12	12	12	12	12	12	12
88	21305-921	PANEL - REAR	1	1	1	1	1	1	1	1	1	1	1	1
90	51625-131	BASE	1	1	1	1	1	1	1	1	1	1	1	1
99	32001-151	CASTOR BRACKET CAP	4	4	4	4	4	4	4	4	4	4	4	4
100	51639-108	CASTOR BRACKET	2	2	2	2	2	2	2	2	2	2	2	2
101	51039-101	CASTOR BRACKET SUPPORT	1	1	1	1	1	1	1	1	1	1	1	1
102	10892-286	CASTOR	4	4	4	4	4	4	4	4	4	4	4	4
103	21009-951	TANK BRACKET	1	1	1	1	1	1	1	1	1	1	1	1
107	Y-12853	WASHER	12	12	12	12	12	12	12	12	12	12	12	12
113	10342-T14	SIDE BURNER ELECTRODE	1	1	1	1	1	1	1	1	1	1	1	1
114	53109-111	SHELF - RIGHT	1	1	1	1	1	1	1	1	1	1	1	1
115	53109-111	SHELF - LEFT	1	1	•	•	•	•	1	1	•	•	•	•
	53109-151	SHELF - SB - LEFT	•	•	1	1	1	1	•	•	1	1	1	1
123	Y-12117	BUSHING	•	•	2	2	2	2	•	•	2	2	2	2
124	53004-271	SIDE BURNER BODY	•	•	1	1	1	1	•	•	1	1	1	1
125	53000-251	SIDE BURNER COVER	•	•	1	1	1	1	•	•	1	1	1	1
126	10390-E10D	SIDE BURNER	•	•	1	•	1	•	•	•	1	•	1	•
	10390-E10E	SIDE BURNER	•	•	•	1	•	1	•	•	•	1	•	1
127	Y-12835	SCREW #6-32 x 1/4	•	•	2	2	2	2	•	•	2	2	2	2
128	53009-951	GRID	•	•	1	1	1	1	•	•	1	1	1	1

PARTS LIST / LISTE DES PIÉCES

[illegible]

